

26th July 2017

SolarSIM-G Quick Start Guide

1. Unpack your SolarSIM box and confirm the contents against the Packing List.
2. Plug the USB drive into your PC and install the SolarSIM DAQ software. Typical file path: E:\SolarSIM-G DAQ SNXXXX Installer\Volume\setup.
3. Plug either end of the USB cable into the COMBOX.
4. Screw either end of the Com Cable into the COMBOX and the other end into your SolarSIM-G.
5. Plug the free end of the USB cable into your PC.
6. Check that the blue LED lights up on the COMBOX.
7. Wait for Windows to install COMBOX drivers
8. Open the SolarSIM DAQ software.
9. Enter the latitude, longitude and elevation of the SolarSIM.
10. Set your data acquisition timer in seconds (to the left of the Start DAQ button).
11. Click 'Start DAQ'.
12. Your SolarSIM will now start acquiring data. Enjoy.
13. The SolarSIM data is saved in .csv format in the following directory:
Program Files (x86)\SolarSIM-G DAQ SNXXXX\Data\

Kind regards,

The Spectrafy Team

PS: Don't hesitate to give us a call at +1 (613) 237 2020 if you have any issues with the Quick Start procedure.